Oki Data CONFIDENTIAL

OKIOFFICE44/OKIFAX4100
RSPL

Related drawings

Drawing No.	Name
40055101TH	FAX NIP-FX048 保守マニュアル
40055101TL	FAX NIP-FX048 Disassembly Drawing

Bom	Use for		Certification Body	
Rev	Date	DCO No.	Contents	Design	Approval
9	2007-08-28	SP7-3637		Hidenori Ueda	Hideki Enomoto
10	2008-08-21	SP9-0135	Change Format(Epsilon)	Kenichi Akiyama	Yasuhiro Kaede

Approval	Design	Name
Hideyuki Kondo	Hidenori Ueda	Recom.spare part.lst
Check		
Date: 1996-06-19	Oki Data Corporation	Drawing No.: 40055101TR

Applicable

Part No.	Printer Series	Destination	Voltage	Model No.	Note
40055101					

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	CASBINET ASSEMBLY(FAX NIP-FX046)	1	40111201	Unit-Printer(100V)	1	-	-	-				-
	CASBINET ASSEMBLY(FAX NIP-FX046)	2	PA4083-1230G001	HOLDER ASSY	1	-	-	-				-
	CASBINET ASSEMBLY(FAX NIP-FX046)	3	YA4116-1228G001	LED HEAD GENERAL SPEC. 31B	1	1	2	4				-
	CABINET ASSEMBLY(FAX NIP-FX046)	4	YX4083-1134G001	CABLE FLAT ASSY	1	5	10	20				-
	CABINET ASSEMBLY(FAX NIP-FX046)	6	40192201	EP Unit Spec.	1	-	-	-	Consumable			-
	CABINET ASSEMBLY(FAX NIP-FX046)	8a	YB4049-1874P001	Power unit AC-DC switch	1	5	10	20				-
	CABINET ASSEMBLY(FAX NIP-FX046)	8b	YB4049-1875P001	Power unit AC-DC switch	1	5	10	20				-
	CABINET ASSEMBLY(FAX NIP-FX046)	9a	40092201	Board-R44	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	9b	40587401	Board-R45	1	3	6	12	VE version			-
	CABINET ASSEMBLY(FAX NIP-FX046)	10a	40044501	Board-UNC	1	3	6	12	US			-
	CABINET ASSEMBLY(FAX NIP-FX046)	10b	40044401	Board-FN5	1	3	6	12	UK, FRANCE			-
	CABINET ASSEMBLY(FAX NIP-FX046)	10c	40044101	Board-DN5	1	3	6	12	GER			-
	CABINET ASSEMBLY(FAX NIP-FX046)	10d	40044303	Board-WN5	1	3	6	12	OEL-INT			-
	CABINET ASSEMBLY(FAX NIP-FX046)	10e	40044307	Board-WN5	1	3	6	12	OKI-INT			-
	CABINET ASSEMBLY(FAX NIP-FX046)	13	40023701	Plate Assy.-Base	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	14	40023901	Bracket-Package	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	15	40236401	Plate Assy.-Shield(HV)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	17	41767001	Frame Assy.-Scanner L	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	18	40021001	Frame Assy.-Scanner(U)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	19c	40022703	OP Panel Assy.	1	-	-	-	LANIER			-
	CABINET ASSEMBLY(FAX NIP-FX046)	19d	40022704	OP Panel Assy.	1	-	-	-	TN			-
	CABINET ASSEMBLY(FAX NIP-FX046)	21a	40025401	Cover-Main	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	21b	40025402	Cover-Main	1	3	6	12	TN			-
	CABINET ASSEMBLY(FAX NIP-FX046)	22a	40025301	Cover-Front	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	22b	40025302	Cover-Front	1	3	6	12	TN			-
	CABINET ASSEMBLY(FAX NIP-FX046)	23a	40025501	Cover-Rear	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	23b	40025502	Cover-Rear	1	3	6	12	TN			-
	CABINET ASSEMBLY(FAX NIP-FX046)	24a	40025601	Cover-NCU	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	24b	40025602	Cover-NCU	1	3	6	12	TN			-
	CABINET ASSEMBLY(FAX NIP-FX046)	25a	40022101	Cover Assy.-Top	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	25b	40022102	Cover Assy.-Top	1	3	6	12	TN			-
	CABINET ASSEMBLY(FAX NIP-FX046)	26	40026101	Spring-TC	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	27	40024001	Guide-Paper(U)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	28	PP4083-6168P001	HEAD SPRING	2	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	29	40024101	Guide-Paper(L)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	30	PB4120-1136P001	KNOB SCREW	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	31	PB4013-3102P001	B SCREW	9	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX046)	32	PB3529-5116P001	B SCREW FA	14	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX046)	33	PB4013-3102P002	B SCREW B	2	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX046)	34	P3-4HH	Screw	1	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX046)	35	PSWW4-6C	Screw	1	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX046)	39	40140801	Bracket-Damper	1	3	6	12				-
	~~CABINET ASSEMBLY(FAX NIP-FX046)~~	~~40~~	~~40148201~~	~~Gear-Damper~~	~~1~~	~~3~~	~~6~~	~~12~~			D	-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	CABINET ASSEMBLY(FAX NIP-FX046)	40	42596601	Damper-Oil	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	41a	40025701	Tray-Document	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	41b	40025702	Tray-Document	1	3	6	12	TN			-
	CABINET ASSEMBLY(FAX NIP-FX046)	42a	40025801	Tray-Paper	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	42b	40025802	Tray-Paper	1	3	6	12	TN			-
	CABINET ASSEMBLY(FAX NIP-FX046)	43a	40375801	Stacker Assy.-Document	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX046)	43b	40375802	Stacker Assy.-Document	1	3	6	12	TN			-
	CABINET ASSEMBLY(FAX NIP-FX046)	44	T2P3-8C	Screw	1	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX046)	50	NB3201-1211P001	CARRIER SHEET	1	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX046)	51	223A7010P0003	TM-6-DC1	1	3	6	12	GER, TN			-
	CABINET ASSEMBLY(FAX NIP-FX046)	52a	40123402	Plate Assy.-PC I/F	1	3	6	12	For OKIOFFICE44			-
	CABINET ASSEMBLY(FAX NIP-FX046)	52b	40123403	Plate Assy.-PC I/F	1	3	6	12	VE version			-
	CABINET ASSEMBLY(FAX NIP-FX046)	53	PP4120-1187P001	Plate-Earth(PCFX)	1	3	6	12	For OKIOFFICE44			-
	CABINET ASSEMBLY(FAX NIP-FX046)	54	40332701	Label-Manual slot	1	-	-	-	For OKIOFFICE44			-
	UNIT-PRINTER	1	YX4083-1510G001	PRINTER UNIT ASSY	1	-	-	-				-
	UNIT-PRINTER	5	YA4130-1024G001	PCB ASSEMBLY HV	1	5	10	20				-
	UNIT-PRINTER	7	T2P3-8C	Screw	1	-	-	-				-
	UNIT-048 OPE PANEL	1a	40022701	OP Panel Assy.	1	3	6	12	ODA/OKI-INT			-
	~~UNIT-048 OPE PANEL~~	~~1b~~	~~40022702~~	~~OP Panel Assy.~~	~~1~~	~~3~~	~~6~~	~~12~~	~~OEL~~		D	-
	UNIT-048 OPE PANEL	1c	40022703	OP Panel Assy.	1	3	6	12	LANIER			-
	UNIT-048 OPE PANEL	1d	40022704	OP Panel Assy.	1	3	6	12	TN			-
	UNIT-048 OPE PANEL	2a	40023401	Sheet-F-048	1	3	6	12	OEL-INT/OKI-INT			-
	UNIT-048 OPE PANEL	2b	40023402	Sheet-F-048	1	3	6	12	UK/FRANCE			-
	UNIT-048 OPE PANEL	2c	40023403	Sheet-F-048	1	3	6	12	GERMANY			-
	UNIT-048 OPE PANEL	2d	40023404	Sheet-F-048	1	3	6	12	ITALY			-
	UNIT-048 OPE PANEL	2e	40023405	Sheet-F-048	1	3	6	12	NORWAY			-
	UNIT-048 OPE PANEL	2f	40023406	Sheet-F-048	1	3	6	12	DENMARK			-
	UNIT-048 OPE PANEL	2g	40023407	Sheet-F-048	1	3	6	12	SWEDEN			-
	UNIT-048 OPE PANEL	2h	40023408	Sheet-F-048	1	3	6	12	HOLAND			-
	UNIT-048 OPE PANEL	2i	40023409	Sheet-F-048	1	3	6	12	SPAIN			-
	UNIT-048 OPE PANEL	2j	40023410	Sheet-F-048	1	3	6	12	ODA (US/CANADA)			-
	UNIT-048 OPE PANEL	2k	40023413	Sheet-F-048	1	3	6	12	LANIER FTZ			-
	UNIT-048 OPE PANEL	2l	40023414	Sheet-F-048	1	3	6	12	TN			-
	UNIT-048 OPE PANEL	2m	40023430	Sheet-F-048	1	3	6	12	CHN			-
	UNIT-048 OPE PANEL	2n	40023431	Sheet-F-048	1	3	6	12	S/R			-
	UNIT-048 OPE PANEL	3a	40023501	Sheet-O-048	1	10	20	40	ODA/OEL-INT/OKI-INT			-
	UNIT-048 OPE PANEL	3b	40023502	Sheet-O-048	1	3	6	12	UK/FRANCE			-
	UNIT-048 OPE PANEL	3c	40023503	Sheet-O-048	1	3	6	12	GERMANY, FTZ			-
	UNIT-048 OPE PANEL	3d	40023504	Sheet-O-048	1	3	6	12	ITALY			-
	UNIT-048 OPE PANEL	3e	40023505	Sheet-O-048	1	3	6	12	NORWAY			-
	UNIT-048 OPE PANEL	3f	40023506	Sheet-O-048	1	3	6	12	DENMARK			-
	UNIT-048 OPE PANEL	3g	40023507	Sheet-O-048	1	3	6	12	SWEDEN			-
	UNIT-048 OPE PANEL	3h	40023508	Sheet-O-048	1	3	6	12	HOLAND			-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	UNIT-048 OPE PANEL	3i	40023509	Sheet-O-048	1	3	6	12	SPAIN			-
	UNIT-048 OPE PANEL	3j	40023510	Sheet-O-048	1	3	6	12	TN			-
	UNIT-048 OPE PANEL	3k	40023520	Sheet-O-048	1	3	6	12	CHN			-
	UNIT-048 OPE PANEL	3l	40023521	Sheet-O-048	1	3	6	12	S/R			-
	UNIT-048 OPE PANEL	4	40023601	Sheet-Cover	1	5	10	20				-
	OPEPAANEL ASSEMBLY	1	40022801	Case-OPE(T)	1	-	-	-				-
	OPEPAANEL ASSEMBLY	2	40086701	Board-O4W	1	3	6	12				-
	OPEPAANEL ASSEMBLY	3	40023001	Holder-LCD	1	-	-	-				-
	OPEPAANEL ASSEMBLY	4	40023101	Button-Function	1	-	-	-				-
	OPEPAANEL ASSEMBLY	5	PP4120-1067P001	TEN KEY	1	-	-	-				-
	OPEPAANEL ASSEMBLY	6a	40023201	Button-Start	1	3	6	12	OKI, TN			-
	OPEPAANEL ASSEMBLY	6b	40023202	Button-Start	1	3	6	12	LANIER			-
	OPEPAANEL ASSEMBLY	7a	40023301	Button-Stop	1	3	6	12	OKI, TN			-
	OPEPAANEL ASSEMBLY	7b	40023302	Button-Stop	1	3	6	12	LANIER			-
	OPEPAANEL ASSEMBLY	9	YB4134-1009P001	LCD	1	3	6	12				-
	OPEPAANEL ASSEMBLY	10	PB4013-3098P006	B SCREW A	14	-	-	-				-
	OPEPAANEL ASSEMBLY	11	PB4120-1113P001	RUBBER CONNECTOR	2	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	1	40019301	Frame-Scanner(L)	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER(L)	2	40019401	Lever-PC1	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	3	40019501	Lever-PC2	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	4	40019601	Roller Assy.-ADF	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	5	40020201	Plate-Earth ADF	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	6	40020601	Piece-Exit	2	6	12	24				-
	FRAME ASSEMBLY-SCANNER(L)	7	40020701	Spring-Exit	2	6	12	24				-
	FRAME ASSEMBLY-SCANNER(L)	8	40127501	CONN Cord-Speaker	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	9	YB4120-1121P001	CONTACT IMAGE SENSOR-A4	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	12	40043301	Plate-Scanner(L)	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER(L)	13	40019801	Plate Assy.-Scanner(R)	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER(L)	14	40020301	Gear-Z95/14	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	15	40020501	Spring-Latch	2	6	12	24				-
	FRAME ASSEMBLY-SCANNER(L)	16	40019701	Plate Assy.-Scanner(B)	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER(L)	17	PB3529-5116P001	B SCREW FA	10	-	-	-				-
	FRAME ASSEMBLY-SCANNER(L)	18	40153801	Spring-Reinforcement	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	19	40025201	Gear-Z38	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	20	40024501	Spring-CIS	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(L)	23	40899901	Spring-Reinforcement_add_work	1	3	6	12				-
	PLATE ASSEMBLY-SCANNER(B)	1	40024401	Plate-Scanner(B)	1	-	-	-				-
	PLATE ASSEMBLY-SCANNER(B)	3	40135301	Photo-Interrupter	2	6	12	24				-
	PLATE ASSEMBLY-SCANNER(R)	1	40024601	Plate-Scanner(R)	1	-	-	-				-
	PLATE ASSEMBLY-SCANNER(R)	2	40084301	Motor-S(FX-048)	1	3	6	12				-
	PLATE ASSEMBLY-SCANNER(R)	3	PB3529-5116P001	B SCREW FA	2	-	-	-				-
	FRAME ASSEMBLY-SCANNER(U)	1	40711701	Frame Assy.-Scanner(U) Partial	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER(U)	2	PP3527-5153P001	BACK-UP PLATE	1	3	6	12				-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	FRAME ASSEMBLY-SCANNER(U)	3	40267001	Separator Assy.-ADF	1	5	10	20				-
	FRAME ASSEMBLY-SCANNER(U)	5	40021401	Spring-Pinch(L)	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(U)	6	40021501	Spring-Pinch(R)	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(U)	8	40021701	Guide-Sensor(B)	2	6	12	24				-
	FRAME ASSEMBLY-SCANNER(U)	9	40481101	Spring-ADF(048)	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(U)	10	40199101	Cord-Earth	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER(U)	11	PB3529-5116P001	B SCREW FA	2	-	-	-				-
	FRAME ASSEMBLY-SCANNER(U)	12	40021201	Roller Assy.-Sensor	1	5	10	20				-
	FRAME ASSEMBLY-SCANNER(U)	13	40022001	Bearing-S	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(U)	14	40020801	Gear-Z31	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(U)	15	40021301	Plate-Support	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(U)	16	40026301	Bar-Discharge	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER(U)	17	40461301	Film-Exit(DOC)	1	3	6	12				-
	COVER ASSEMBLY-TOP	1	40022201	Cover-Top	1	-	-	-				-
	COVER ASSEMBLY-TOP	2	40022301	Holder-LED	1	3	6	12				-
	COVER ASSEMBLY-TOP	3	40022401	Guide-Document(L)	1	-	-	-				-
	COVER ASSEMBLY-TOP	4	40022501	Guide-Document(R)	1	-	-	-				-
	COVER ASSEMBLY-TOP	6	PP4128-1268P001	PLATE EXIT	2	6	12	24				-
	COVER ASSEMBLY-TOP	7	PP4083-2024P001	EJECT ROLLER A	2	6	12	24				-
	COVER ASSEMBLY-TOP	8	PP4083-2328P003	PINION GEAR B	1	3	6	12				-
	COVER ASSEMBLY-TOP	10	PB3529-5116P001	B SCREW FA	2	-	-	-				-
	COVER ASSEMBLY-TOP	11	40093201	Spring-Support	2	6	12	24				-
	COVER ASSEMBLY-TOP	12	40175801	Film-Exit(A)	2	6	12	24				-
	COVER ASSEMBLY-TOP	13	40022601	Spring-D	1	3	6	12				-
	PLATE ASSEMBLY-BASE	1	40023801	Plate-Base	1	-	-	-				-
	PLATE ASSEMBLY-BASE	2	LP-7024	RUBBER A	2	-	-	-				-
	PLATE ASSEMBLY-BASE	3	40026001	Sheet-Insulation	1	3	6	12				-
	PLATE ASSEMBLY-BASE	4	40128001	Cord-Flat(FUJI CARD)	1	5	10	20				-
	PLATE ASSEMBLY-BASE	5	40197001	Sheet-FG	1	-	-	-				-
	PRINTER BASE FRAME UNIT	1	PP4083-1502G001	FRAME BASE ASSY	1	3	6	12				-
	PRINTER BASE FRAME UNIT	3	PP4083-1191P001	SENSOR PAPER E	2	6	12	24				-
	PRINTER BASE FRAME UNIT	4	40721301	Separator Assy	1	3	6	12				-
	PRINTER BASE FRAME UNIT	6	PP4083-1246P001	SPRING COMPRESSION S	1	3	6	12				-
	PRINTER BASE FRAME UNIT	7	PA4083-1193G001	SENSOR ASSY TONER	1	3	6	12				-
	PRINTER BASE FRAME UNIT	8	PB4083-1172P001	MOTOR PULSE	1	3	6	12				-
	PRINTER BASE FRAME UNIT	9a	YA4083-1600G002	EP UNIT SPEC.	1	-	-	-	For ODA			-
	PRINTER BASE FRAME UNIT	9b	YA4083-1600G003	EP UNIT SPEC.	1	-	-	-	For OEL/OKI-INT			-
	PRINTER BASE FRAME UNIT	10a	40035001	Toner-Cartridge-4w	1	-	-	-	For ODA			-
	PRINTER BASE FRAME UNIT	10b	YA4083-1450G003	Toner-Cartridge	1	-	-	-	For OEL/OKI-INT			-
	PRINTER BASE FRAME UNIT	11	PB4083-1129P001	ROLLER HOPPING	1	3	6	12				-
	PRINTER BASE FRAME UNIT	12	PP4083-1128P001	HOLDER ROLLER H	1	3	6	12				-
	PRINTER BASE FRAME UNIT	13	PB4083-1127P001	MAGNET H.	1	3	6	12				-
	PRINTER BASE FRAME UNIT	14	PA4083-1133G001	SHAFT HOPPING ASSY	1	3	6	12				-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	PRINTER BASE FRAME UNIT	15	NK2-10-SUS	KNOCK PIN	1	3	6	12				-
	PRINTER BASE FRAME UNIT	16	PP4083-1143P001	GEAR IDLE R	1	3	6	12				-
	PRINTER BASE FRAME UNIT	17	PP4083-1184P001	IDLE GEAR 2R	1	3	6	12				-
	PRINTER BASE FRAME UNIT	18	PP4083-1142P001	GEAR R	1	3	6	12				-
	PRINTER BASE FRAME UNIT	19	PP4083-1181P001	GEAR IDLE M	1	3	6	12				-
	PRINTER BASE FRAME UNIT	20	PP4083-1189P001	PLATE EARTH A	1	3	6	12				-
	PRINTER BASE FRAME UNIT	21	PP4083-1188P001	PLATE SIDE M	1	3	6	12				-
	PRINTER BASE FRAME UNIT	22	PP4083-1182P001	GEAR IDLE P	2	6	12	24				-
	PRINTER BASE FRAME UNIT	23	PP4083-1183P001	GEAR IDLE 3R	1	3	6	12				-
	PRINTER BASE FRAME UNIT	24	PP4083-1165P001	PLATE TENSION	1	3	6	12				-
	PRINTER BASE FRAME UNIT	25	PP4083-1185P001	GEAR IDLE HEAT	1	3	6	12				-
	PRINTER BASE FRAME UNIT	26	PP4083-1186P001	GEAR IDLE EA	1	3	6	12				-
	PRINTER BASE FRAME UNIT	27	PP4083-1187P001	GEAR IDLE EB	1	3	6	12				-
	PRINTER BASE FRAME UNIT	28	PP4083-1170P001	SHAFT DRIVE E	1	3	6	12				-
	PRINTER BASE FRAME UNIT	29	40074601	Roller Eject	2	6	12	24				-
	PRINTER BASE FRAME UNIT	30	PP4083-1141P001	BEARING REGIST	4	16	30	60				-
	PRINTER BASE FRAME UNIT	31a	PB4083-1140P001	ROLLER REGIST	1	3	6	12				-
	PRINTER BASE FRAME UNIT	31b	40457001	ROLLER REGIST	1	3	6	12	For CHN			-
	PRINTER BASE FRAME UNIT	32	41802101	Film-Guide_F	1	3	6	12				-
	PRINTER BASE FRAME UNIT	33	PP4083-1151P001	GEAR T	1	3	6	12				-
	PRINTER BASE FRAME UNIT	34a	YB4083-1150P002	ROLLER TRANSFER	1	3	6	12				-
	PRINTER BASE FRAME UNIT	34b	40456901	ROLLER TRANSFER	1	3	6	12	For CHN			-
	PRINTER BASE FRAME UNIT	35	PP4083-1136P001	SPRING PRESSURE L	1	3	6	12				-
	PRINTER BASE FRAME UNIT	36	PP4083-1161P001	BEARING BU	2	3	6	12				-
	PRINTER BASE FRAME UNIT	37	PB4083-1160P002	ROLLER PRESSURE B	1	3	6	12				-
	PRINTER BASE FRAME UNIT	38	PP4083-1233P001	GUIDE PAPER R	1	3	6	12				-
	PRINTER BASE FRAME UNIT	39	PP4083-1232P001	GUIDE PAPER L	1	3	6	12				-
	PRINTER BASE FRAME UNIT	40	PP4083-1231P001	HOLDER PAPER	1	3	6	12				-
	PRINTER BASE FRAME UNIT	41	PP4083-1192P001	SENSOR PAPER EXIT	1	3	6	12				-
	PRINTER BASE FRAME UNIT	42	41802001	Spring-Hopper_F	1	3	6	12				-
	PRINTER BASE FRAME UNIT	47	PP4083-1137P001	SPRING PRESSURE R	1	3	6	12				-
	PRINTER BASE FRAME UNIT	49	PP4083-1241P001	GUIDE SHEET	1	3	6	12				-
	PRINTER BASE FRAME UNIT	51a	YX4083-1200G001	HEAT ASSY	1	5	10	20	120V			-
	PRINTER BASE FRAME UNIT	51b	YX4083-1200G002	HEAT ASSY	1	5	10	20	230V			-
	PRINTER BASE FRAME UNIT	52	40034001	SPRING STOPPER	1	3	6	12				-
	PRINTER BASE FRAME UNIT	53	PB4091-6047P001	CAUTION LABEL T	1	3	6	12	230V			-
	PRINTER HEAT ASSY	1	PB4083-1202P001	ROLLER HEAT	1	5	10	20				-
	PRINTER HEAT ASSY	2a	PB4083-6103P004	HALOGEN LAMP	1	5	10	20	120V			-
	PRINTER HEAT ASSY	2b	PB4083-6103P005	HALOGEN LAMP	1	5	10	20	230V			-
	PRINTER HEAT ASSY	3	PB4083-1204P001	THERMOSTAT	1	5	10	20				-
	PRINTER HEAT ASSY	4	PB4083-1205P001	THERMISTOR	1	5	10	20				-
	PRINTER HEAT ASSY	5	PB4083-1213P001	CORD HEAT	1	5	10	20				-
	PRINTER HEAT ASSY	6a	PB4012-3213P001	CAUTION LABEL J	1	3	6	12	CHN			-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	PRINTER HEAT ASSY	6b	40274101	label-Caution KOREA	1	3	6	12	SR			-
	CABLES	1	40048101	CONN Cord-Wire(AC)	1	3	6	12				-
	CABLES	2	40040001	CONN Cord-Wire(OPE)	1	3	6	12				-
	CABLES	3	40040201	CONN Cord-Wire(CIS)	1	3	6	12				-
	CABLES	4	40040301	CONN Cord-Wire(PC1/2)	1	3	6	12				-
	CABLES	5	105A1070C0003	TFC-20-10-10	1	3	6	12				-
	CABLES	6	105A1070C0004	TFC-23-11-14	1	3	6	12				-
	CABLES	7	105A1073C4002	SSC-40-12	1	3	6	12				-
	CABLES	8	1051070C0001	TFC-16813	1	3	6	12				-
	CABLES	9	105A1067C1001	FPC-25-12	1	3	6	12				-
	CABLES	10a	236A3161P0002	FTC2-001-9SG	1	3	6	12				-
	CABLES	10b	YB3522-1297G001	TEL/LINE CORD	1	3	6	12	GER TN			-
	CABLES	11a	YS4011-1329P002	AC CORD	1	3	6	12	OKI-INT			-
	CABLES	11b	YS3512-1485P001	AC CORD	1	3	6	12	ODA Supplied by ODA.			-
	CABLES	11c	236A6058P0001	4622-007-0092	1	3	6	12	OEL			-
	CABLES	11d	40483802	AC Cord A	1	3	6	12	CHN			-
	CABLES	12	YS4111-5581P001	CORD(TEL1-TEL2)	1	3	6	12	GER, TN			-
	CABLES	13	105A1062C0002	0443-167251	1	3	6	12	For PC I/F use			-
	CABLES	14	105A1068C1004	SFC-8	1	3	6	12	For TEL/LINE Cord use			-